



Instruction for the Electrical Contractor

1. At each vent (inside looking out) fit a junction box to the right hand side of each transom for the 24 volt DC rack and pinion electric drive.
2. At each vent install a 3 core 1.5 square fire tuff wire from each junction box to the control panel location.
3. At the control panel location fit a 230 volt AC supply using a 13 amp unswitched spur.
4. At the control panel location install an I/O unit.